

Are You Ready For Installation? A Project Checklist

Thank you for choosing us to install your kitchen appliances! In order for your installation to go as smooth as possible, please carefully check the guidelines listed below. It is also very important to consult the manufacturer specifications which provide precise and critical details that must be followed. If you are not ready, please notify us immediately so that your project can be rescheduled. If you are unsure if you are ready, please call us at 770-451-0136.

PLEASE NOTE: Due to scheduling volume, installations book out approximately 4 weeks in advance. Because of this, it may take some time to reschedule a project that is not ready. The below guidelines are very important and should be reviewed early in the process in order to keep your installation on schedule. Additional charges apply for return trips due to preparation errors.

Cabinetry

- Cabinets should be fully installed.
- Confirm that “finished furniture returns” or “cleats” are installed for any fully flush appliance.
- Confirm that all cabinet opening sizes are accurate (width, height, and depth) according to appliance specifications.
- Confirm custom hood canopy opening size is correct for your particular hood liner.

Electrical

- Confirm the electrical supply is placed in the required location, based on appliance specifications.
- Confirm the proper voltage and amperage have been supplied for each appliance.
- Confirm the correct receptacle for your particular appliance is fully installed (no bare wires). Receptacle types can vary depending on the appliance.
- Power supply to the home should be ON in order to properly test appliances.

Plumbing

- Confirm the water supply and drain connection are placed in the required locations, based on appliance specifications.
- Confirm the drain connection is the correct size for your particular appliance.
- Confirm the gas supply is the correct size for your particular appliance.
- Confirm the gas supply is placed in the required location.
- Confirm that a shut-off valve has been installed on the gas supply line.
- Water and gas supply to the home should be ON in order to properly test appliances.

Ventilation

- Confirm the correct size duct work has been installed, based on appliance specifications.
- Confirm the duct work has been installed in the correct location, based on appliance specifications.
- For hood liner installations, confirm there is adequate duct work available within the decorative canopy to connect to.
- For ceiling mount or island hoods, confirm required blocking/support has been installed into the ceiling area for the hood system to be anchored to.
- Make up air dampers should be installed by HVAC personnel prior to appliance installation, if required. Confirm with your contractor regarding make up air requirements.

Countertops & Backsplash

- Ideally, countertops and backsplash should be fully installed prior to appliance installation.
- Confirm that the countertop cutout size is accurate according to cooktop, rangetop, and/or downdraft specifications.
- Confirm the backsplash does not interfere with the opening dimension of a decorative hood canopy.

Flooring

- Flooring should be fully installed, including into areas beneath an appliance.

Delivery Access

- Ideally, driveways should be completed in order for the delivery trucks to safely deliver appliances.
- Stairs should be completed and easily accessible.
- Open access to the home should be available (dumpsters and/or building material should not be blocking access to the home).

**Questions about your installation?
Call us! 770-451-0136**